



Spaceborne Infrared Atmospheric Sounder – GEO (SIRAS-G)

Thomas Kampe
Ball Aerospace & Technologies Corp
AIRS Science Team Meeting
March 30, 2007



SIRAS-G Instrument Incubator Overview and Objectives

■ Objective

- Develop instrument technology for IR atmospheric sounding from GEO and LEO
- Validate operational performance in a laboratory demonstration
- Generate a design recommendation for space flight instrument


SIRAS-G

IIP

**Awarded in
2003**

**Technology
Development
Partners:**

**NASA/Jet
Propulsion
Laboratory**




TRLin= 2 TRL current= 4

Evolution of the SIRAS-G Program


AIRS

- The Atmospheric Infrared Sounder (AIRS) provides 3-dimensional maps of air and surface temperature, water vapor, and cloud properties.
- AIRS has 2378 spectral channels, AIRS has a spectral resolution more than 100 times greater than previous IR sounders



SIRAS-1999

- Ball supported JPL
- Designed, built & cryogenically tested 12-15.4um spectrometer
- Integrated AIRS detector array
- Developed test facilities for testing the spectrometer at cryogenic temperatures



**SIRAS-1999
Spectrometer In Test
Dewar**


SIRAS-G

- Builds on the success of SIRAS-1999
- Demonstrates a complete IR imaging spectrometer operating over the 3.4 – 4.9 um region
- Laboratory demo instrument incorporates a 4-mirror reflective collimator, a 4-element refractive camera, a flat grating, and a large area FPA
- Instrument concept uses several spectrometers to provide full coverage from 3.4 – 15.4 um




Demo Instrument Optimized for Large Format Array

- Teledyne Hawaii 1-RG Array
- 1024 x 1024 Format Array
- 0.018-um Pixel Pitch
- Spatial and spectral resolution elements = 2 pixels
- Image of slit is smaller in length than FPA:
 - Avoids illuminating inactive pixels or leads & wires around FPA
 - Provides margin for alignment of FPA to slit
 - Since ends of slit are on active pixels, alignment of the slit can be measured
 - Simplifies alignment of FPA to detector housing and optical system




Alignment Fiducials in SIRAS-G OBA

Correct placement of alignment fiducials is critical for efficient assembly



Mirror Fiducial Detail










Fiducial Detail

Collimator Mirror 1

Camera Lens Elements Bonded into Separate Cells

- The refractive lens elements for the camera were fabricated by ISP Optics
- Delivered on 8/15/2005
- All elements meet requirements
- As-built data will be used to re-optimize system prior to assembly
- Lens elements bonded using Dow Corning 93-500 Silicone Adhesive
- Low out-gassing
- Wide operational temperature range: Remains compliant to 100 K
- Extensive BATC heritage
- Bond thicknesses and widths sized to minimize stress with temperature





Athermal mount design approach documented in SPIE paper: Herbert, J. (2006), Proc. SPIE Vol. 6288, 62880J, Current Developments in Lens Design and Optical Engineering VII; Pantazis Z. Mouroulis, Warren J. Smith, R. Barry Johnson; Eds.

| Element | Bondline Thickness determined from Deluzio Equation |
|------------------------|---|
| Lens 1 Ge, 86 mm dia. | 0.037" |
| Lens 2 Si, 92 mm dia. | 0.048" |
| Lens 3 Ge, 92 mm dia. | 0.040" |
| Lens 4 ZnS, 72 mm dia. | 0.030" |



Laboratory Demo Instrument Completed


All Major Hardware Subsystems have been integrated into the Laboratory Demo Instrument




Flat Ruled Grating



SIRAS-G Flight-like FPA Package




SB-235 CryoCooler




WFOV Refractive Camera



SIRAS-G Aft-Optics Assy




Optical Bench








Desired Performance Achieved in Cryogenic Testing




- Measurements show low spectral smile and keystone distortion
- Dispersed MWIR spectrum obtained by SIRAS-G Demo Instrument



SIRAS-G Measured Spectra





Warm Shield Implementation



- Lab Demo demonstrated feasibility of Multi-Stage Warm Shields
- High performance warm shield eliminates need for true cold shield
- This is the first known application of warm shields to IR imaging spectrometers
- Mature design methodology in place to support warm shield designs for additional wavelength ranges, etc.
- Design, geometry and warm shield positioning well understood for extrapolation to other spectrometers
- Excel spreadsheet provides insights into sensitivities
- Test methodology for validating warm shield performance under development


What's a Warm Shield? And, Why Use it?




- SIRAS-G do not have a cold stop in the traditional sense of locating the stop at the detector dewar.
- The stop is located at the gratings because that improves the control of the spectrometer distortions (keystone and smile)
- Not having a cold stop introduces thermal background seen by the detectors
- This can be reduced by:
 - Using warm shields
 - Reducing the temperature of the cavity
- Multi-stage warm shield concept originally developed on SIRAS-G

Impact of Using Warm Shields (LWIR Pathfinder)


Ch 1, Cycle 4
 $T \approx 112.9$ K




Ch 1, Cycle 4b
 $T \approx 112.6$ K



Ch 2, Cycle 4
 $T \approx 112.9$ K



Ch 2, Cycle 4b
 $T \approx 112.6$ K



- Channel 1 and 2 data sets from cycle 4 and 4b. Channel 1 is largely unchanged and channel 2 has much higher near field thermal background



Radiative Transfer Tools Developed to Provide Insight to Instrument Performance


Example: Impact of LW Cutoff on Temperature Sounding

Objective:

- Evaluate the impact on retrievals of reducing FPA performance or eliminating channels near 15 μm
 - Advantage is potential reduction in cost and/or technical development
 - These channels have greatest sensitivity to temperature in upper troposphere and lower stratosphere (UT/LS)


Results:

- 0.2K improvement in upper troposphere (<220 mb) and lower stratosphere with 650 cm^{-1} cutoff
- No significant additional temperature information is obtained with inclusion of the SMW (1650-2250 cm^{-1}) water vapor band
 - < 2250 cm^{-1} region only sensitive to low level temperature
 - > 2250 cm^{-1} could improve UT/LS temperature but problem with NLTE in 4.3 μm region



Spectrometer Co-registration Errors

- For an ideal imaging spectrometer, all spectral channels would see the same ground pixel at the same time
- Optical distortion, FPA-to-FPA mechanical alignment errors and relative magnification errors in camera optics can lead to misregistration of channels
- In regions where strong scene gradients exist (e.g. near clouds), registration errors produce spectral artifacts by mixing spectra from neighboring pixels
- The spectral errors are not random noise in the measurement but are correlated across the band affecting science data in a complex way
- ***The impact of spectrometer registration errors on science data must be quantified using an end-to-end measurement simulation approach***





Candidate LEO Mission Parameters

- First mission being studied is an AIRS Follow-On Mission
 - Low-Earth Orbit; enhanced spatial resolution
 - Mission focused on retrieval of atmospheric temperature profiles, water vapor profiles, ozone column and cloud properties
 - Spectral coverage and resolution optimized for these parameters

Candidate AIRS Follow-On Mission Key Measurement Requirements:

- Spatial resolution: 1-km
- Swath coverage: 1650 km (TBR)
- Radiometric Noise < 0.2K (TBR)

| Measurement | Accuracy (req.'ed : goal) |
|----------------------|------------------------------------|
| Surface Temperature | 1K : 0.5K |
| Temperature profiles | 1K (rms) (1-km layers < 100mb) |
| Humidity profile | 20% : 10% (2-km layers < 100mb) |
| Column Ozone | 20% |

| Measurement | Spectral Range (cm ⁻¹) | Min. res (cm ⁻¹) | Goal res (cm ⁻¹) | Notes |
|----------------------|---|---------------------------------|---------------------------------|--|
| Temperature profiles | 650 - 768 2228 - 2255 2380 - 2410 | 0.5 2.0 2.0 | 0.5 | Higher spectral resolution improves T sounding throughout range |
| Humidity profiles | 1370-1610 | 2.0 | 0.5 | Weaker water lines near 2600 cm ⁻¹ used AIRS |
| Ozone Column | 1001-1069 | 0.5 | TBD | Very high resolution necessary for profile info. |
| Surface Temperature | 750-1200 | ~1.0 | 0.5 | Several channels: 750-1235 cm ⁻¹ and >2400 cm ⁻¹ |
| Dust properties | 750-1200 | ~1.0 | 0.5 | Higher resolution improves UT/LS retrievals |
| Cloud properties | 750-1200 | ~1.0 | 0.5 | 3 channels: 8,10,12 mm |


Coordinated Path to Space-Flight Programs

Increasing Technology Readiness & Science Capability

Ball will be proposing an Airborne Demonstration of SIRAS-G for recent NASA ROSES AO


Air Pollution & Chemistry from GEO

- Notional Mission Requirements:
- UV-VIS spectrometer: 310-600 nm
- Infrared spectrometer: 3.75-15 mm
- Spatial resolution 4-km
- Regional coverage in 6 minutes
- Disk coverage in 30 minutes
- Baseline concept developed under SIRAS-G IIP



ARIES

Advanced Remote Sensing Imaging Earth Science Spectrometer



A space based remote sensing measurement concept to support future earth system science

BUILDING ON AIRS AND MODIS


ARIES (JPL)

- Enabling technology for ARIES
- Proposed by JPL, NOAA/NESIS, JCSA, GSFC, UMBC) for Decadal Survey
- AIRS heritage
- "MODIS Spatial Resolution with AIRS Spectral Resolution and NEdT"
- 1-km footprint
- 3.6-15.4μm; 4800 channels; $\lambda/\Delta\lambda \approx 1500$
- Pushbroom geometry is easily met using SIRAS technology
- Baseline concept being developed in conjunction with JPL




SIRAS Airborne Demo

Instrument optimization Based on Science Requirements



Large Area FPAs



Active Coolers




LWIR Spectrometer Demo SIRAS-1999





MWIR imaging Spectrometer Demo SIRAS-G 2006

OSSE modeling to guide definition of instrument parameters based on retrieval sensitivities



AIRS Follow-On Instrument

- Low-Earth Orbit; enhanced spatial resolution
- Mission focused on retrieval of atmospheric temperature profiles, water vapor profiles, ozone column and cloud properties
- Spectral coverage and resolution optimized for these parameters
- Spatial resolution: 1-km
- Swath coverage: 1650 km
- Radiometric Noise < 0.2K
- Concept study documented in Tech Report 33130SYS-10 LEO Point Design



Laboratory

Ball Aer

Airborne

Spaceborne




SIRAS-G Instrument Incubator Program

PI: Thomas Kampe, Ball Aerospace & Technologies Corp.



Objective

- Develop instrument technology for IR atmospheric sounding from GEO and LEO
- Validate operational performance in a laboratory demonstration
- Generate a design recommendation for space flight instrument



Accomplishments

- Radiative transfer forward-modeling tools & OSSE model developed to link instrument requirements/performance to science requirements & used for flight concept development
- Developed single-channel MWIR lab demo that integrates flight-like spectrometer, active cooling, flight-like IR FPA and electronics
- Spectrometer design developed for low distortion (spectral smile & keystone) & excellent image quality. Design form is extendable to multi-leg configuration (3-15 μm spectral coverage)
- Advanced technology multi-stage warm shield concept demonstrated
- Demo instrument tested in cryogenic environment using test methodology and apparatus developed on BATC IRAD (keystone distortion, smile, MTF, SRF, dispersion)

Technology Development Partners
NASA/Jet Propulsion Laboratory

TRL_{in}= 2 TRL_{current}= 4